



Unlock the power of the FC20 portable breath alcohol tester, a precision instrument providing you with the fastest most reliable results.

The FC20 offers users a fully integrated solution for all your screening & evidentiary alcohol testing needs.

Lifeloc FC20

Professional Breath Alcohol Tester

Unlock the Power of Alcohol Testing

Lifeloc FC20

12441 West 49th Avenue, Suite 4 Wheat Ridge, COLORADO 80033 303.431.9500 | 800.722.4872 fax: 303.431.1423 | www.lifeloc.com

All of Lifeloc's Breath Alcohol Testers are DOT/NHTSA approved.

Product Innovation

- Menu Driven Software
- Easily guides users through the testing process
- Can be customized to your testing needs
- Breath Pressure Sensor
 - · Test will not activate until subject begins blowing
 - Additional security against an uncooperative subject
- Security Features
 - Password Protection prevents unauthorized changing of calibration and/or user settings
 - User selectable Calibration/Cal Check Lockout
 - Lockout available by time or number of tests
- AlcoMark® Software Compatible
- Data Management Solutions
 - Multiple data entry fields for unique Subject ID, User ID or location information
 - Optional Keyboard
- 4000 Test Memory
- Printing Capabilities
 - Portable Thermal Printer or PC printing with AlcoMark® Software

Precision Instrument

- Platinum Fuel Cell Sensor
 - Superior accuracy and long life
- Alcohol specific
- Double Pump Sampling System
 - Unsurpassed Passive Testing
 - Perfect for open containers
 - · Rapid multiple subject testing
- Rapid & Repeatable Test Taking
 - Immediate response on negative, <10 seconds on positive tests
 - Immediate recovery on negative, <30 seconds on positive tests
- Best In Class Operating Temperature
 - 0-55°C or 32-130°F
- Barometric Pressure Sensor (optional)

Ease of Use

- User Selectable Test Modes
 - Auto, Manual and Passive options
 - · Passive can be turned on or off
- Dual Trigger Modes
 - End of Breath: test taken at end of breath sample
 - Precise Volume: test taken after detecting 1.5L of breath
- Large Backlit LCD Display
 - · Excellent day or night visibility
 - Full 64 character display
 - Easy to understand prompts with full text alerts
 - Power saving Auto Shut-off
- Sturdy & Rugged Design
 - Optional rubber grip protects the unit from damage
 - Fits securely in your hand, small enough to fit in a shirt pocket
 - Heavy duty components and rugged case
- Long Battery Life
 - 160 hours of "on time" or up to 6000 tests
 - 4AA Alkaline or NiMH rechargeable batteries

Five Star Customer Care

- Live, Onsite Technical Support
- Fastest Repairs in the Industry
 - 5 days or less for up to 5 units or it's free
- Comprehensive Service Packages
 - Gold, Silver & Platinum packages offer a full spectrum of services and warranties
- Exceptional Value
 - Tiered products and pricing for every budget
 - Volume Discounts
- Training Solutions & Supplies
 - Comprehensive Training Packages
 - Calibration Equipment
 - Unit Supplies and Accessories
- Manufactured & Serviced Responsibly in USA

