EASYCAL[®] G2 Automatic Calibration Station



Lifebc Professional Breath Alcohol Tester

The EASYCAL G2 is the next generation in workplace alcohol breath testing compliance. The G2 automates every step of EBT calibration and checks with its ID enabled tanks and simplified process.

From start to finish; just cradle your EBT, power on and the EASYCAL G2 does the rest.



Unlock the Power of Alcohol Testing

EASYCAL[®] G2 Automatic Calibration Station



In the office or on the road, mandated cal-checks and calibrations are effortless and worry-free. Like your Lifeloc EBT, EASYCAL G2 is engineered with Lifeloc accuracy and reliability.

Fast and Simple to Use

- One-touch calibration and calibration checks
- Large color touchscreen for easy navigation
- Reduces gas usage
- Significantly faster calibrations than the competition
- Displays date, time, and power status
- Calibration and cal-check progress bar
- Allows for up to 100 individual operators

Compliance Management Features

- Utilizes ID enabled tanks that automatically read and store tank value, expiration date and lot code
- Cylinder Expiry Lockout prevents the use of expired gas
- Low Gas Alert warns of low gas volume and shows percent of tank remaining
- Calibration Warning helps prevent an inadvertent calibration after a positive test
- Auto Altitude Correction
- Security allows you to assign, enable or disable users and passwords
- Sequence Software ensures all cal/cal-checks are performed and documented correctly
- Serial Numbers are read and stored with each event
- Print Log stores all cal/cal checks across unlimited EBTs

As per Lifeloc Technologies' Quality Assurance Plans (QAP) and referenced in section 40.233 of 49CFR Part 40; only individuals trained and qualified as

| Display | Full Color Digital LCD Resistive Touchscreen |
|-----------------------------------|--|
| Cylinder Size | Accomodates 34L, 60L, 105L and 116L gas cylinders |
| Available Gas Standards | 0.040, 0.080, 0.100** |
| EBT Seat Sensor | Ensures Proper Device Seating |
| Cylinder Pressure Sensor | Automatically checks tank volume |
| Barometric Pressure Sensor | Automatically Corrects Altitude |
| Recovery Time | Immediate |
| Calibration Time | < 2 minutes |
| Calibration Check Time | < 30 seconds |
| Operating Temperature Range | 50° - 113° F (10° - 45° C) |
| User Selectable Power Options | 9VDC 3A Regulated 6 C Alkaline Auto Sleep Mode |
| Power Save Feature | Auto Shutoff |
| Dimensions | Approx. 10.6" L x 9.25" W x 5.3" H (270 x 235 x 135 mm) |
| Weight | 3 Pounds (48 ounces, 1360 grams) |
| Printer Communication Standard | Bluetooth |
| Software Updates | Field updatability via USB |
| Memory | Approx. 10,000 records before overwriting |
| Unit of Measure | BAC Standard International UOM Available |
| Language | English Standard Additional Languages Available. |
| Date/Time | User Selectable International Date and Time Formats |
| Certifications | CE |
| Housing | Ruggedized ABS Plastic |
| Warranty | 2 year Limited Parts and Labor |
| | |

**Other Common Standards Available Upon Request

All of Lifeloc's Breath Alcohol Testers are DOT/NHTSA approved.

12441 West 49th Avenue, Suite 4 Wheat Ridge, CO 80033 303.431.9500 | 800.722.4872 fax: 303.431.1423 www.lifeloc.com

EasyCal* is a registered trademark of Lifeloc Technologies, Inc.

calibration technicians may perform the required calibrations.

©2013 Lifeloc Technologies, Inc MK-0163 Rev. 1.2